

# Dual 2.5" SATA Mobile RAID USB 3.0


User Manual English




LINDY No. 43108



## **Device Overview**






## **Hardware Installation**

1. Unlock upper and lower covers, then open the door.



- 2. Place one or two hard drive(s) in the slot. Make sure the SATA connector is lined up with the connector inside the Mobile Rack.
- **3.** Carefully push the hard drive into the Mobile Rack, so that the drive's SATA connector is seated securely, then close the door and lock it. It must be in the lock position when in use. This prevents unexpected removal while working.
- **4.** Adjust the DIP switch to set the storage policy:



- **5.** Plug the included switching power adapter into the enclosure's power adapter jack, then plug the switching power adapter into a reliable power source.
- **6.** Use the included USB 3.0 cable to plug the USB 3.0 Dual 2,5" SATA Mobile RAID into a USB 3.0 port of your computer and switch it on. Make sure the Power LED is lit.

**Caution:** Changing the RAID mode destroys data stored on the Mobile Rack, If you have saved data on the drives, back up data before following these steps.

#### Note:

- 1. Users are advised to disable the device from the computer before unplugging the cable or turning off the device.
- 2. If the hard drive does not support ACCESS signal, then the HDD ACTIVE LED will not flash when the hard drive is in use.
- 3. If the system cannot detect the device, please go to device management and enable it.
- 4. Do not open the door or turn off the power of the Mobile Rack while the hard drive is busy, this may cause damage to you hard drive.
- 5. It must be in the lock position when in use. This prevents unexpected removal while working.
- 6. Do not force the door to open while it is locked, otherwise, you will damage the lock.

## **Driver Installation**

Windows will automatically detect and install the drivers. An additional drive icon will appear in MY COMPUTER when the USB 3.0 Dual 2,5" SATA Mobile RAID is connected.

# Disconnecting from the Computer

Use Windows' Safely Remove Hardware utility to turn off or disconnect the USB 3.0 Dual 2,5" SATA Mobile RAID.

#### Windows 7

- 1. Verify that the HDD access LED is OFF before proceeding
- 2. Click the Safely Remove Hardware and Eject Media icon located in the taskbar
- 3. Click the "USB Mass Storage Device"
- 4. When the message *Safe to Remove Hardware* pops up, you can safely turn off or unplug the enclosure

#### **Windows Vista**

- 1. Verify that the HDD access LED is OFF before proceeding
- 2. Double click the *Unplug* or *Eject Hardware* icon located in the system tray
- 3. Highlight "USB Mass Storage Device", click Stop
- 4. Click OK twice, then Close
- 5. You can safely turn off or unplug the enclosure

#### Windows XP / Server 2003 & 2008

- 1. Verify that the HDD access LED is OFF before proceeding
- 2. Double click the Safely Remove Hardware icon located in the system tray
- 3. Highlight "USB Mass Storage Device", click Stop, OK, then Close
- 4. You can safely turn off or unplug the enclosure

### Radio Frequency Energy, Certifications

#### **FCC Warning**

This equipment has been tested and found to comply with the limits for a Class B Digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- · Consult the dealer or an experienced technician for help

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation

#### **CE Statement, EMC Compatibility**

This device complies with EN Standards EN55022 and EN55024 according to the relevant EC EMC Directive. It must be used with shielded cables only to maintain EMC compatibility.

Dieses Produkt entspricht den einschlägigen EMV Richtlinien der EU und darf nur zusammen mit abgeschirmten Kabeln verwendet werden.

#### **LINDY Herstellergarantie**

LINDY gewährt für dieses Produkt über die gesetzliche Regelung hinaus eine zweijährige Herstellergarantie ab Kaufdatum. Die detaillierten Bedingungen dieser Garantie finden Sie auf der LINDY Website aufgelistet bei den AGBs.



# WEEE (Waste of Electrical and Electronic Equipment), Recycling of Electronic Products

In 2006 the European Union introduced regulations (WEEE) for the collection and recycling of all waste electrical and electronic equipment. The wheelie bin symbol shown indicates that this product must not be disposed of with household waste. Instead the product must be recycled in a manner that is environmentally friendly. For more information on how to dispose of this product, please contact your local recycling centre or your household waste disposal service. Each individual EU member state has implemented the WEEE regulations into national law in slightly different ways. Please follow your national law when you want to dispose of any electrical or electronic products.

More details can be obtained from your national WEEE recycling agency.

#### **Germany / Deutschland**

Die Europäische Union hat mit der WEEE Direktive umfassende Regelungen für die Verschrottung und das Recycling von Elektro- und Elektronikprodukten geschaffen. Diese wurden von der Bundesregierung im Elektro- und Elektronikgerätegesetz – ElektroG in deutsches Recht umgesetzt. Dieses Gesetz verbietet vom 24.März 2006 an das Entsorgen von Elektro- und Elektronikgeräten über die Hausmülltonne! Diese Geräte müssen den lokalen Sammelsystemen bzw. örtlichen Sammelstellen zugeführt werden! Dort werden sie kostenlos entgegen genommen. Die Kosten für den weiteren Recyclingprozess übernimmt die Gesamtheit der Gerätehersteller.



**LINDY No 43108** 

1<sup>st</sup> Edition, August 2011

www.lindy.com